

# ECCENTRICHE

## ECCENTRIC



**STANDARD**  
STANDARD



**MINI**  
MINI



### ECCENTRICA STANDARD - DX - ECCENTRIC STANDARD - RIGHT

Cod.	TYPE	d 9	d 8	Cod.	TYPE	d 9	d 8
<b>NUT.16.ST</b>	ERX16	32	M22x1,5	<b>NUT.40.ST</b>	ERX40	63	M50x1,5
<b>NUT.20.ST</b>	ERX20	35	M25x1,5	<b>NUT.50.ST</b>	ERX50	78	M64x2
<b>NUT.25.ST</b>	ERX25	42	M32x1,5	<b>NUT.60.ST</b>	ERX60	84	M70x1,5
<b>NUT.32.ST</b>	ERX32	50	M40x1,5				



### ECCENTRICA STANDARD - SX - ECCENTRIC STANDARD - LEFT

Cod.	TYPE	d 9	d 8	Cod.	TYPE	d 9	d 8
<b>NUT.16.ST.L</b>	ERX16	32	M22x1,5 sin	<b>NUT.32.ST.L</b>	ERX32	50	M40x1,5 sin
<b>NUT.20.ST.L</b>	ERX20	35	M25x1,5 sin	<b>NUT.40.ST.L</b>	ERX40	63	M50x1,5 sin
<b>NUT.25.ST.L</b>	ERX25	42	M32x1,5 sin				



### ECCENTRICA MINI - DX - ECCENTRIC STANDARD - RIGHT

Cod.	TYPE	d 9	d 8	Cod.	TYPE	d 9	d 8
<b>NUT.8.MINI</b>	ERX8M	12	M10x0,75	<b>NUT.20.MINI</b>	ERX20M	28	M24x1
<b>NUT.11.MINI</b>	ERX11M	16	M13x0,75	<b>NUT.25.MINI</b>	ERX25M	35	M30x1
<b>NUT.16.MINI</b>	ERX16M	22	M19x1				



### ECCENTRICA MINI - SX - ECCENTRIC STANDARD - LEFT

Cod.	TYPE	d 9	d 8	Cod.	TYPE	d 9	d 8
<b>NUT.11.MINI.L</b>	ERX11M	16	M13x0,75 sin	<b>NUT.20.MINI.L</b>	ERX20M	28	M24x1 sin
<b>NUT.16.MINI.L</b>	ERX16M	22	M19x1 sin	<b>NUT.25.MINI.L</b>	ERX25M	35	M30x1 sin